

IMPORTANT

The following information will guide you in selecting the correct hose for your central vacuum system

Pigtail or Direct Connect?

Electric hoses are available with either 'Pigtail' or 'Direct Connect' configuration. The difference between pigtail and direct connect is how it connects to the wall inlet valve.

PIGTAIL HOSE CONFIGURATION



The pigtail configuration electrified hose comes with an **8ft supply cord** (pigtail)

This hose is designed to work with **STANDARD** low-voltage wall inlet valves

The pigtail plugs into a nearby regular **~110v electrical outlet**

DIRECT CONNECT HOSE CONFIGURATION

The direct connect configuration electrified hose has a 2-pronged hose-end cuff



This hose is designed to **ONLY** work with electrified wall valves

The direct connect hose will **NOT** work with a standard low-voltage wall inlet valve

The electrified wall valve has the low-voltage connection as well as a built-in **~110v plug**



The 2-pronged male plug on the hose connects into the **~110v wall inlet valve**

The electrified wall inlet valve has markings **7A, 125v, 60Hz**

